

How it works...

1 Dual Heating Elements

High quality Quartz Infrared Element
Plus Custom Porcelain-Coated Coil-
Wire Element

2 Optimal Heating

The heat chamber increases the temperature
of the air approximately 115°F

3 Balanced Heat

Warm air gently enters the room and keeps
the temperature difference between floor
and ceiling to within 2 - 3 degrees

4 Scroll Fan

Ultra quiet scroll style bearing
fan for circulating the air through the
heater and the area being heated

5 Filtration

Room temperature intake air passes
through a high efficiency lifetime filter
(not shown) that removes dust and dirt
from the air before it enters the heater.



6 Auto-Reset

Programmed Auto Restart so heater
will automatically restart at 68°F
after a power outage



7 Full Function Remote

Allows you to choose Hi or Low setting,
adjust the temperature & count-down
timer, turn the heat off/on.



8 On / Off Switch

Lighted master power switch on the
front controls all power to the
heater.

DOUBLE SAFETY DESIGN™ System



9 Safety

Two High Limit Safety
switches turn the unit off
in the unlikely event of the
unit overheating

