

"MODE" BUTTON INSTRUCTIONS

PUSH ONCE	Choose °C or °F	Use UP and DOWN arrows to pick C or F readout.
PUSH TWICE	Set Countdown TIMER	Use UP and DOWN arrows to set desired countdown hours. To reset TIMER OFF, turn POWER OFF.
PUSH THREE TIMES	Check Room Temperature	This is the air temperature the heater is measuring from the sensor in the back. This may vary from a wall thermostat.

To disable the remote control feature, press and hold MODE for three seconds.
The display will flash 3 times indicating the remote function is turned-off.